

1. While inserting the computer for the first time the appropriate USB line that the UT382 install, the computer will hint an information, such as figure, automatically eight.



Figure 1

2. Next move, the choice "Install from a list or specific location (Advanced)", such as figure 2.




Figure 2

3. Next move, the choice "Don't search. I will choose the driver to install.", such as figure, 3




Figure 3

4. Next move, the choice "install from the disk" figure 4




Figure 4

5. Next move, specify to install the path very important, in UT382 factory go together with of connect a people's CD, have the the USB Drive this document to clip, pick out other gearings document "SiUSBXp.inf" to carry on the gearing. Such as the figure 5.



Figure 5

6. Next move, choose to still continue. Such as the figure 6.



Figure 6

7. Next move. Such as the figure 7.



Figure 7

8. Next move, install to complete.